
FREEMOTION

FITRIG 4' MONKEY BAR RIG

Model No. FMDY4MBR.1 Serial No.

Write the serial number in the space above for reference.




QUESTIONS?

If you have questions, or if parts are damaged or missing, please see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual.

ACAUTION

Read all precautions and instructions in this manual before using this equipment. Keep this manual for future reference.

OWNER'S MANUAL



freemotionfitness.com

TABLE OF CONTENTS

IMPORTANT PRECAUTIONS	
WARNING DECAL PLACEMENT	
ASSEMBLY	
PART LIST	
EXPLODED DRAWING	
MAINTENANCE	
HOW TO CONTACT CUSTOMER CARE	
I IMITED WARRANTY	

IMPORTANT PRECAUTIONS

WARNING: To reduce the risk of serious injury, read all important precautions and instructions in this manual and all warnings on the strength equipment before using the strength equipment. Freemotion Fitness assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

- It is the responsibility of the owner to ensure that all users of the strength equipment are adequately informed of all precautions, have read and understood all warning and caution decals, and are informed of how to use the strength equipment properly.
- All users of the strength equipment should be instructed to report any injury or strength equipment irregularity to facility staff immediately.
- 3. Before beginning any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.
- 4. Use the strength equipment only on a level surface. Cover the floor beneath the strength equipment to protect the floor.
- It is the responsibility of the owner to ensure that there is enough clearance around the strength equipment for all of the exercises that will be performed.
- Using the included anchors, anchor the strength equipment to the floor to provide maximum stability before using the strength

- equipment. The anchors must be installed by a qualified installer.
- 7. Make sure that all parts are properly tightened before each use of the strength equipment.
- 8. Keep children under age 16 and pets away from the strength equipment at all times.
- The strength equipment should not be used by any user weighing more than 400 lbs. (182 kg).
- 10. Never allow more than 2 users to use the monkey bars at the same time. Never allow more than 5 users to use the strength equipment at the same time.
- 11. Always wear athletic shoes for foot protection while exercising.
- 12. Use the strength equipment only as described in this manual.
- 13. Over exercising may result in serious injury or death. If you feel faint, if you become short of breath, or if you feel pain while exercising, stop immediately and cool down.

WARNING DECAL PLACEMENT

This drawing shows the location(s) of the warning decal(s). If a decal is missing or illegible, see the front cover of this manual and request a free replacement decal. Apply the decal in the location shown. Note: The decal(s) may not be shown at actual size.

1

AWARNING

DEATH OR SERIOUS CRIPPLING INJURY CAN OCCUR IF THE BARBELL DROPS SUDDENLY. TO AVOID INJURY, FOLLOW THESE PRECAUTIONS:

- BEFORE USING: Read all warnings and obtain instruction on the use of this machine.
- ALWAYS set both spotters when using machine.
- ALWAYS use a human spotter in addition to machine spotters.
- PROPER spotter height depends on the exercise performed. Adjust as follows:
- Remove all weight from the barbell.
 For squats, perform the exercise
- 2. For squats, perform the exercise and determine the lowest comfortable position without your body contacting the floor. FOR SQUATS, NEVER PLACE THE SPOTTERS BELOW THE HEIGHT INDICATED ON THE MACHINE. For other exercises, perform the movement and select the lowest point of barbell travel without the barbell contacting your body.
- Position both spotters to stop the barbell at this point. Ensure that both spotters are completely seated on the machine.
- 4. Load weights onto the barbell and carefully perform the exercise.
- Visually ensure the barbell latch is fully engaged and seated in the hooks before releasing the load and exiting the machine.
- •DO NOT REMOVE this label. Replace when worn or damaged.

2

AWARNING

HEAVYSpotters must be used at all times.

3

AWARNING

- Read and follow all warnings and instructions and obtain proper instruction prior to use.
- Misuse of this equipment may result in serious injury.
- Do not allow children on or around machine.
- Keep body, clothing, and hair free and clear of all moving parts.
- Replace label if damaged, illegible, or removed.
- illegible, or removed.
 Max user weight: 400 lbs.




4

AWARNING

To reduce the risk of serious spinal injury, do not place spotters below this level when doing SQUAT exercises.



Spotters must be used at all times when this machine is used.



FREEMOTION is a registered trademark of ICON Health & Fitness, Inc. FORMULA 409 is a registered trademark of The Clorox Company. SIMPLE GREEN is a registered trademark of Sunshine Makers, Inc.

ASSEMBLY

Thank you for selecting the FREEMOTION® FITRIG 4' MONKEY BAR RIG strength equipment. Please read the following important instructions before you begin assembling the strength equipment.

- Because of the size and weight of the strength equipment, assemble it in the location where it will be used. Make sure that there is enough clearance around the strength equipment for all of the exercises that will be performed.
- Place all parts of the strength equipment in a cleared area and remove the packing materials; do not dispose of the packing materials until the strength equipment is fully assembled.
- Assembly requires two persons, your adjustable wrenches or set of wrenches, and your step ladder.
- To assemble the strength equipment, refer to the PART LIST below and the EXPLODED DRAWING on page 5.
- Leave all bolts (6) and locknuts (8) slightly loose until you have assembled all parts of the strength equipment. Then, fully tighten the bolts and locknuts. See the small inset drawing on page 5. Make sure that 1 to 2 threads of each bolt extend past the attached locknut.

- Turn all of the uprights (1) so that the numbers (A) face the direction show on page 5.
- Turn all of the single bars (3) and monkey bars (4) so that the gussets (B) face downward.
- The strength equipment is compatible with an array
 of optional accessories. Up to 5 users can train at
 the same time with dip, squat rack, monkey bar, and
 landmine stations and a variety of other stations. And
 with optional storage accessories, optional weights
 and bars can be stored directly on the strength
 equipment. To purchase accessories at any time,
 see the back cover of this manual.

IMPORTANT: Attach only FREEMOTION accessories to the strength equipment; attaching other accessories will void the warranty.

IMPORTANT: Before the strength equipment is used, have the included anchors installed by a qualified installer.

IMPORTANT: After the strength equipment has been used for 48 hours, retighten all bolts (6) and locknuts (8).


PART LIST

Model No. FMDY4MBR.1 R0321A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	4	Upright	6	28	5/8" x 4 1/2" Grade-5 Bolt
2	2	Crossbar	7	56	5/8" Washer
3	2	Single Bar	8	28	5/8" Grade-5 Locknut
4	3	Monkey Bar	*	4	Anchor Set (4 per set)
5	4	Square Cap	*	_	Owner's Manual

Note: Specifications are subject to change without notice. For information about ordering replacement parts, see the back cover of this manual. Extra hardware may be included. *These parts are not illustrated.

EXPLODED DRAWING



MAINTENANCE

For optimal performance of the strength equipment and to reduce the chances of injury to users, you must perform preventive maintenance on a regular basis. Instruct all personnel to perform the procedures described in this section. Personnel must also record and report any accident. To maintain the strength equipment's warranty, use only FREEMOTION parts for repair or replacement. If there are any questions or concerns, see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual.

DAILY MAINTENANCE

General Cleaning

Clean the strength equipment using a soft cloth dampened with a light solution of mild soap and warm water. If necessary, use a soft bristle brush with the solution.

Then, rinse the area thoroughly using a soft cloth dampened with clean water, and thoroughly dry it.

Difficult Stains

Spray the stain with a non-abrasive household cleaner such as FORMULA 409® cleaner, SIMPLE GREEN®, or a similar product. Rub the stained area gently and let the cleaning solution sit for a few minutes.

Then, rinse the area thoroughly using a soft cloth dampened with clean water, and thoroughly dry it.

Repeat these steps, if necessary, using a soft bristle brush.

CAUTION: When using any cleaning product, try it first in an unnoticeable place to ensure that there is no damage to the material. Follow the directions and the safety precautions of the manufacturer of each cleaning product used. Freemotion Fitness and its vendors cannot be held liable for damage or injuries resulting from the use or misuse of cleaning products. IMPORTANT: Do not use abrasive cleaners, which may scratch the strength equipment. Strong cleaners and abrasives will damage decals; use caution around decals. Do not use solvents such as lacquer thinner, kerosene, gasoline, or similar liquids.

WEEKLY MAINTENANCE

Hardware

Check all screws, bolts, and locknuts, and tighten them if necessary.

NOTES

HOW TO CONTACT CUSTOMER CARE

If you have questions after reading this manual, or if parts are damaged or missing, please contact Customer Care at one of the phone numbers or addresses listed below. Please note the model number, serial number, and name of the product (see the front cover of this manual) before contacting Customer Care. If you are ordering replacement parts, please also note the key number and description of each part (see the PART LIST and the EXPLODED DRAWING in this manual).

In the United States

Call: 1-800-201-2109, Mon.—Fri. 6 a.m.—6 p.m. MT Email: customercare@freemotionfitness.com

Write:

Freemotion Fitness 1500 South 1000 West Logan, UT 84321-9813 United States

Outside the United States

Call: 001-800-527-5417 or 001-435-786-3521, Mon.–Fri. 6 a.m.–3 p.m. USA Mountain Time Email: intlcustomercare@freemotionfitness.com

LIMITED WARRANTY

WARRANTY PERIODS AND COVERAGE

Freemotion Fitness warrants the frame to be free from defects in workmanship and material under normal use and service conditions for ten (10) years. Labor is warranted for one (1) year. The warranty period commences on the invoice date of purchase. Any parts repaired or replaced during this warranty period will be warranted for the remainder of the original warranty period.

CONDITIONS AND LIMITATIONS

The following will void the warranty on this product:

- This warranty applies only to the original owner and is non-transferable.
- The labor warranty applies only to products sold in the USA and Canada. Contact your authorized Freemotion Fitness dealer for details on labor coverage in your country.
- 3. Any misuse, abuse, or improper service.
- 4. Users who weigh more than the maximum user weight listed in this manual.
- The attachment of accessories other than FREEMOTION accessories.
- Damage caused by moving the product or improper storage including moving or storing the product on its side.
- 7. Use or storage of the product outdoors or in high-humidity environments including spa and pool areas.

This warranty shall not apply to the following:

1. The powder coating; screws, bolts, washers, and locknuts; and cosmetic items such as decals and placards.

- Pick-up and delivery or freight charges involved with a repair.
- 3. Any problem as a result of improper assembly or delivery.

WHAT TO DO IF SERVICE IS REQUIRED

Freemotion Fitness warranty service may be obtained by contacting the authorized dealer from which you purchased this product. Make sure to retain your original invoice and serial number information. If this product experiences a failure under the warranty terms set forth, Freemotion Fitness shall provide at their option either repair, replacement, or refund of the purchase price. Freemotion Fitness compensates service providers for warranty trips within their service area. You may be charged additionally for service calls beyond this service area.

Freemotion Fitness is not responsible or liable for indirect, special, or consequential damages arising out of or in connection with the use or performance of the product; damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, or cost of removal or installation; or other consequential damages. Some regions do not allow the exclusion or limitation of consequential damages. Accordingly, the above limitation may not apply to you. This warranty gives you specific rights, and you may have other rights that vary from region to region.

TO CONTACT FREEMOTION FITNESS

See HOW TO CONTACT CUSTOMER CARE above.